



19.95 EUR  
incl. 19% VAT, plus [shipping](#)

**Support:** [Manual \[DE\]](#) | [Manual \[EN\]](#)

This adapter-set consists of 2 parts. The cables are to be integrated into the Voom main connector cable (see manual). The inner part gets connected to the P4-connector or 5.25" power connector of your power supply. The outer part provides a DC-plug which you can connect to the power-connector of the All-In-One cables provided with the CTF display series. This way your TFT display will be powered entirely by the power supply of your carpc.